

IC Socket - for 8-pin 0.3" Chips - Pack of 3

PRODUCT ID: 2202

There are multiple versions of this item. Please select one from the options below:

for 08-pin 0.3" Chips

for 16-pin 0.3" Chips

for 20-pin 0.3" Chips

for 28-pin 0.3" Chips

for 28-pin 0.6" Chips

for 40-pin 0.6" Chips

IN STOCK

1

ADD TO CART

1-9

10-99

100+

ADD TO WISHLIST

DESCRIPTION


TECHNICAL DETAILS

DESCRIPTION

An IC (Integrated Circuit) socket allows you to insert and remove chips easily from an assembled kit or project

This item contains 3 of the 8 pin 0.3" wide version. Best used with chips that have 8 pins (2x4) and have 0.3" pin spacing.

These are often used for soldering into a Perma Proto or PCB so that you can replace and swap chips easily. What's nice about IC sockets is that they are the same pin spacing and size so you don't have to redesign the board! For our example photo, we put the socket into an [Adafruit Perma-Proto Breadboard](#) but any solderable PCB or protoboard will work great. Not recommended for solderless breadboards, the pins are not long enough.



TECHNICAL DETAILS


- 10mm x 10mm x 8mm / 0.4" x 0.4" x 0.3"
- Weight: 0.5g




MAY WE ALSO SUGGEST...




28-pin ZIF socket



Op Amp - Dual Rail-to-Rail -




IC Socket - for 28-pin 0.3"



40-pin ZIF socket




Professional IC Extraction




IC Socket - for 28-pin 0.6"



IC Socket - for 16-pin 0.3"



IC Socket for 40-pin 0.6"



IC Socket - for 20-pin 0.3"



IC Sockets - Packs of 3 -

DISTRIBUTORS [EXPAND TO SEE DISTRIBUTORS](#)

[CONTACT](#)

[SUPPORT](#)

[DISTRIBUTORS](#)

[EDUCATORS](#)

[JOBS](#)

[FAQ](#)

[SHIPPING & RETURNS](#)

[TERMS OF SERVICE](#)

[PRIVACY & LEGAL](#)

[ABOUT US](#)

ENGINEERED IN NYC Adafruit®

*"Two aesthetics exist: the passive
aesthetic of mirrors and the active
aesthetic of prisms" - Jorge Luis
Borges*



4.9 ★★★★★
Google
Customer Reviews